

## Release note

Version	Action	Modification
v2.6_B1209	Bug fixed:	Machine does not respond when MP1 layer2 searching at 44.1KHz
	New Feature:	Play MPEG1 Layer3 file
v2.7_B0117	New Feature:	Decoding MPEG2 layer 3 and MPEG2.5 layer 3
		Options of repeat playback
		Show software type in USB serial number
v2.8_B0210	New Feature:	Add MP1 layer 3 Encoder
	Change:	Removed file list and auxiliary menu when switch between system menus
		Refresh speed for PPM table
	Bug fixed:	In EDIT menu, sound wave picture does not show properly
		When recording is paused, slide on RECORD key, recording cannot start automatically
		When recording is paused, press LEFT or RIGHT key, machine does not respond
		Playback a small sound file, when reach the file end, machine cannot stop automatically
	When choose randomly repeat playback, machine cannot automatically skip the unrecognized file	
	In RECORD mode, press and hold PLAY key till machine is shut down, number of files would not change	
v2.9_B0309	Bug fixed:	Machine cannot read sound energy data accurately from a MPEG 1 layer 2 quantum
v2.9_B0316	Bug fixed:	in EDIT menu, when set marker point B to the end of a sound file, machine does not respond
v2.92_B0405	New Feature:	In MANAGEMENT mode, when delete a file, its auxiliary folder can be removed simultaneously
		G.729 file could be edited
	Change:	Recording time displays as HH:MM:SS format
	Bug fixed:	In PRE REC mode, AGC does not activated automatically
		When VOR recording is paused, if stop recording, file cannot be automatically saved
	Adjust AGC during recording, no simultaneous change associates to adjustment	
	The machine will display as XXXX when the character could not display	
v2.93_B0414	Bug fixed:	the item "fmt.samplebit" in the BWF format for MPEG2 Layer 2 is zero
		Add choices for input sound mixing
		Press MENU key once for inserting time and jump to that point; twice for selecting marker ;three times for UNDO; and four times for selecting zoom.
	New Feature:	

v3.0	New Feature:	Short press AB once to select point A; twice for selecting point B. Long press AB to cancel the selected portion. Short press AB to switch between A and B when there is an selected portion.
		Add Dutch language
	Change:	Cancel the searching speed auto-increasing function in record and play window. Add choices for setting searching speed in the menu
		In edit window, move the selected setting portion function to AB key. OK key has the functions of adding marks and save as for the selected portion.
		Cancel the zoom function in up and down key, add 100 frames jump function
In left and right keys, cancel the auto-accelerating searching function; cancel jump function by short pressing marker. Add single point searching function.		
Make the xxx-1 file when modifying and fixing file		
v3.11	Change:	In EDIT, when there is no selected portion, Press OK, it will not start "save as".
		Change AGC mode, cancel AGC target level setting; fix AGC target level to -14.4dBFS. When open AGC, equipment gain decreases by 3 db, audio input will move 2bit to the right automatically.
v3.12	Change:	when recording, the mark function is moved to Menu key; OK key is for pause
		At starting of recording, save the file serial number
v3.13	Change:	in old firmware version, it is not possible to adjust the recording level of internal MIC, when the analogue gain of internal MIC is at maximum 10db
v3.13_B0911	Bug fixed:	in recording mode, the initial value of the menu is inaccurate
		in editing, the save as bar doesn't move, and machine freezes when pressing OK key several times.
V3.17_B0421	Bug fixed:	When the disc is full with the recording files, or the disc is full by copying files through U disc, files are lost, or recorder is hung.
V3.17_B0405	Bug fixed:	After formatting, APP is lost when copy files through U disc.
V3.17_B0412	Bug fixed:	When disc is full, pushing the recording key, the file number is increased but the there is no file added.
V3.18_B0704	Bug fixed:	During the 30 seconds flush period, due to the code_pool pre-recorder buffing, the coding data is lost. U disc.
V3.18_B0710	New Feature:	Increase the alarming voltage; add remind note when the disc is full; Add low voltage, or when the disc is full, the liquid crystal will become brighter.
	Bug fixed:	After the time extension is canceled, when the recording is "paused", it is not able to make record.
V3.18_B0723	New Feature:	Press OK when the recorder is not recording, if VOR is on, it goes directly into the recording but "pause" status.
		After start the recorder, when VOR is on, it goes directly into the recording but "pause" status.

V3.19_B1011	Bug fixed:	1 is added to the file name in BWF file head.
V3.20_B1210	Bug fixed: Change:	In version 3.19, the input is 6db less. In EDIT, cancel the auto screen saver function.
V3.21_B1214	Bug fixed:	HOLD key is not working when entering into Testing mode.
V3.22_B0305	Bug fixed:	In EDIT, after several "save as" for the new file, the recorder freezes